

CZ Obsah balení (E) Pakendi sisu (E) Περιεχόμενα
 HU Tartalom (V) Saturs (T) Turinys (L) Zawartość
 BG Съдържание (SK) Obsah (F) İçindekiler (U) Зміст




x1



x1



x1



x1



x2



x2


CR2032

















x2



x1









CZ Úvodem (E) Παράρτημα (U) Kezdő lépések (V) Darba sajkása (T) Darbo pradžia
 L Przygotowanie do użycia (U) Načínání de bází (SK) Zaciňovanie (U) 3 чоро позначати



CZ Párování **ES** Sidurime **GR** Ζεύξη **HU** Összehangolás
LV Sasaitššana **LT** Pirišimas **PL** Nawiązanie połączenia
RO Conexare **SK** Párovanie **TR** Eşleşirme
UA Прив'язування

CZ Volitelné funkce **ES** Usavõimatused **GR** Προαιρετικές λειτουργίες
HU Opcionális funkciók **LV** Papildus funkcijas **LT** Papildomos funkcijos
PL Funkcje dodatkowe **RO** Caracteristici opționale **SK** Voliteľné funkcie
TR Opsiyonel özellikler **UA** Додаткові можливості



	Hello	Ding Dong	Westminster	Marimba	Piano	Bell	Telephone	Soft Alert
	•	•					•	•
	•	•	•	•			•	•
	•	•	•	•	•	•	•	•



CZ Odstranění poruch **ES** Kui vajad lisa abi **GR** Επίλυση προβλημάτων **HU** Hibakeresés
LV Problēmu novēršana **LT** Gedimo paieška **PL** Usuwanie usterek **RO** Depanare
SK Riešenie problémov **TR** Destek **UA** Пошук та усунення несправностей

livewell.honeywell.com



32313850-001 Rev.A